



## Pin Configuration for MSD600M

Page 1/2

DK-Audio A/S  
 Marielundvej 37 D  
 2730 Herlev, Denmark  
[info@dk-audio.com](mailto:info@dk-audio.com)  
[www.dk-audio.com/](http://www.dk-audio.com/)

<b>UTILITY MODULE</b>			
<i>9-Pole DSUB Female</i>			
+ Vcc	12 - 15 V	Pin 4	
Power ground		Pin 5	
RS232	TX	Pin 2	
RS232	RX	Pin 3	
AES sync.	Hot	Pin 8	
	Cold	Pin 9	
	GND	Pin 1	
<i>15-Pole DSUB (VGA) Female</i>			
GND		Pin 5, 6, 7, 8, 10	
H-Sync.		Pin 13	
V-Sync.		Pin 14	
Red		Pin 1	
Green		Pin 2	
Blue		Pin 3	

<b>INPUT MODULE 1 AES/EBU &amp; 2 Analogue</b>			
<i>15-Pole DSUB Female</i>			
<i>Analogue Channel 1</i>	Hot	Pin 15	
	Cold	Pin 8	
	GND	Pin 7	
<i>Analogue channel 2</i>	Hot	Pin 14	
	Cold	Pin 6	
	GND	Pin 13	
<i>AES/EBU</i>	Hot	Pin 9	
	Cold	Pin 2	
	GND	Pin 1	
<i>GND</i>		Pin 4, 10	



**Pin Configuration for MSD600M**  
Page 2/2

**DK-Audio A/S**  
Marielundvej 37 D  
2730 Herlev, Denmark  
[info@dk-audio.com](mailto:info@dk-audio.com)  
[www.dk-audio.com/](http://www.dk-audio.com/)

<b>INPUT MODULE 2 or 4 AES/EBU</b>			
<i>15-Pole DSUB Female</i>			
<i>AES/EBU 1</i>	<i>Hot</i>	<i>Pin 2</i>	
	<i>Cold</i>	<i>Pin 9</i>	
	<i>GND</i>	<i>Pin 1</i>	
<i>AES/EBU 2</i>	<i>Hot</i>	<i>Pin 11</i>	
	<i>Cold</i>	<i>Pin 3</i>	
	<i>GND</i>	<i>Pin 10</i>	
<i>AES/EBU 3</i>	<i>Hot</i>	<i>Pin 15</i>	
	<i>Cold</i>	<i>Pin 8</i>	
	<i>GND</i>	<i>Pin 7</i>	
<i>AES/EBU 4</i>	<i>Hot</i>	<i>Pin 14</i>	
	<i>Cold</i>	<i>Pin 6</i>	
	<i>GND</i>	<i>Pin 13</i>	
<i>GND</i>		<i>Pin 4, 12</i>	

<b>OUTPUT MODULE 1 AES/EBU &amp; 2 Analogue</b>			
<i>15-Pole DSUB Female</i>			
<i>Analogue Channel 1</i>	<i>Hot</i>	<i>Pin 15</i>	
	<i>Cold</i>	<i>Pin 8</i>	
	<i>GND</i>	<i>Pin 7</i>	
<i>Analogue channel 2</i>	<i>Hot</i>	<i>Pin 14</i>	
	<i>Cold</i>	<i>Pin 6</i>	
	<i>GND</i>	<i>Pin 13</i>	
<i>AES/EBU</i>	<i>Hot</i>	<i>Pin 9</i>	
	<i>Cold</i>	<i>Pin 2</i>	
	<i>GND</i>	<i>Pin 1</i>	
<i>GND</i>		<i>Pin 4, 10</i>	